PennRadiant.com PTU Series Floor Level Coverage

GUIDELINES FOR DETERMINING RADIANT PATTERN:

Y FEET = (1.7 X Mounting Height) + Heater Length **X FEET** = 2.2 X Mounting Height

Example: PTU125-30' mounted at 18 Feet (Heater length is approximately 16 feet)

Y Feet = $(1.7 \times 18') + (16') = 46.6$ **feet**

X Feet = $2.2 \times 18' = 39.6$ **feet**



NOTE: Always observe the minimum recommended mounting heights shown on the specification sheet and use U-Tubes for spot heating applications

